

Included Items:

- Wi-Fi Adapter
- Large Security Cover



Quick Installation Guide

IDSX4 Wi-Fi Adapter Kit

Revision A
P/N E744804

Learn more about Elo at [EloTouch.com](https://www.elotouch.com)

America

Tel +1 408 597 8000
EloSales.NA@elotouch.com

Europe (EMEA)

Tel +32 16 930 136
EMEA.sales@elotouch.com

Asia Pacific

Tel +86 (21) 3329 1385
EloAsia@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.


No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.




Caution: Remove power to the IDSX4 Display before installing or un-installing WiFi adapter

1. Remove Wi-Fi connection security cover with philips head screw driver.



2. Connect Wi-Fi adapter, place large security cover over adapter and reinstall screw. (Large security cover included with Wi-Fi adapter kit)



3. Log in to the IDSX4 Display local webpage to complete Wi-Fi setup. Instructions to complete Wi-Fi setup are in document QIG590425 named *IoT(EloView) for IDSX4*.

Scan the QR code below to access QIG590425 directly online.



<http://docs.elotouch.com/QIG590425.PDF>

Note: If the LAN port on the IDS Display is connected, the LAN port will be prioritized over the Wi-Fi adapter for network functionality.