

MPG Series

OLED Monitor

MPG 341CQPX QD-OLED (3DD0)

User Guide

Contents

| Getting Started | 3 |
|------------------------------|----|
| Package Contents | 3 |
| Installing the Monitor Stand | 4 |
| Adjusting the Monitor | 5 |
| Monitor Overview | 6 |
| Connecting the Monitor to PC | 9 |
| OSD Setup | 10 |
| Navi Key | 10 |
| Hot Key | 10 |
| OSD Menus | 11 |
| G.I | 12 |
| Gaming | 13 |
| Professional | 14 |
| Image | 15 |
| Input Source | 16 |
| PIP/PBP | 17 |
| Navi Key | 18 |
| Settings | 18 |
| MSI OLED Care | 19 |
| Specifications | 22 |
| Preset Display Modes | 24 |
| Troubleshooting | 28 |
| Safety Instructions | 29 |
| TÜV Rheinland Certification | 31 |
| Regulatory Notices | 32 |

Revision

V1.0, 2024/09

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

| Monitor | MPG 341CQPX QD-OLED | | | |
|---------------|---|--|--|--|
| Documentation | Quick Start Guide | | | |
| | Stand | | | |
| Accessories | Stand Base with Screw(s) | | | |
| Accessories | Screw(s) for Wall Mount Bracket(s) | | | |
| | Power Cord | | | |
| | Ultra High Speed HDMI™ Cable (Optional) | | | |
| Cables | DisplayPort Cable (Optional) | | | |
| Cubics | USB Upstream Cable (Optional) (for USB Type-B Upstream Port) | | | |




/ Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country and model.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective packaging. Align the stand to the monitor groove.
- 2. Push the stand towards the monitor groove until it locks in place.
- 3. Connect the base to the stand and tighten the base screws to secure the base.
- Make sure the stand assembly is properly installed before setting the monitor upright.





Important


- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.

Adjusting the Monitor

This monitor is designed to maximize your viewing comfort with its adjustment capabilities.




• Avoid touching the display panel when adjusting the monitor.






Monitor Overview




| 1 | Power LED | | |
|----|---|------------------------------|--|
| | Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode. | | |
| 2 | Power Jack | | |
| 3 | Macro Key | | |
| 9 | To activate OSD Application. | | |
| 4 | Navi Key | | |
| 5 | Power Button | | |
| 6 | HDMI TM Connector Michoernmon MULTIMEDIA INTERFACE | | |
| | Supports HDMI™ CEC, 3440x1440@240Hz as spe | ecified in HDMI™ 2.1. | |
| 7 | HDMI TM Connector MICH-SEPRITION MULTIMEDIA RYTERFACE | | |
| | Supports 3440x1440@240Hz as specified in HDMI™ 2.1. | | |
| 8 | DisplayPort | | |
| | Supports 3440x1440@240Hz as specified in Disp | layPort 1.4. | |
| 9 | USB Type-C Port | | |
| | This port supports DisplayPort Alternate (DP Alt) Mode and up to | USB Type-C Power Delivery | |
| | 20V/4.9A (98W) power delivery. | 5V / 3A | |
| | Important | 9V / 3A | |
| | Your USB-C signal source and cable | 12V / 3A 15V / 3A | |
| | must support DisplayPort Alternate | 20V / 4.9A | |
| | Mode to enable video output to the monitor. | 201/4.// | |
| 10 | USB 2.0 Type-A Port | | |



Kensington Lock


Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Connect the power cord to the monitor power jack. (Figure A)
- 4. Plug the power cord into the electrical outlet. (Figure B)
- **5.** Turn on the monitor. (Figure C)
- **6.** Power on the computer and the monitor will auto detect the signal source.





For optimal performance, please remove the protective film from the display panel before use.



OSD Setup

This chapter provides you with essential information on OSD Setup.




Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


Press (OK):

- launching the On-Screen Display (OSD)
- entering submenus
- confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus





The following settings will be grayed out when HDR signals are received:

- Night Vision
- Low Blue Light
- Brightness
- Contrast

- Color Temperature
- Optix Scope
- PIP/PBP
- Al Vision

<u>G.I.</u>

| 1st Level Menu | 2nd/3rd Level Menu | | Description | |
|-----------------|--------------------|--------|--|---|
| KVM | Auto Upstream | | Auto allows the monito between USB input sou mice or other USB devi | ırces, such as keyboards, |
| | Type C | | Users can also designa Type-C as the only USE | ite Upstream port or USB 3 signal source. |
| Smart Crosshair | Icon | None | Through AI algorithm, the visibility of in-game Users can select the cocrosshair. | e crosshair. |
| | Color | White | | |
| | | Red | | |
| | Desiries | Auto | | |
| | Position Reset | | | |
| Optix Scope | Scope Size | Small | The center point will zo | |
| | | Medium | is enabled, user can ad the "Scope Size" and "S | ljust the details through Scope Ratio" settings. |
| | Scope Ratio | x1.5 | Smart Crosshair and 0 | ptix Scope can be |
| | x2 | | enabled at the same time. Activating Optix Scope will affect: | |
| | | x3 | Affected Function | Function Status |
| | OFF ON | | » Adaptive-Sync » PIP/PBP | Set to OFF |
| | | | » Screen Size 1:1 | Set to Auto |

Gaming

| 1st Level Menu | 2nd/3rd Level Menu | | Description | |
|----------------|--------------------|---------------|--|--|
| Game Mode | Premium Color | | Use Up or Down Button to select and preview | |
| | User | | mode effects. | |
| | FPS | | Press the OK Button to confirm and apply your mode type. | |
| | Racing | | | |
| | RTS | | | |
| | RPG | | | |
| Night Vision | OFF | | This function optimizes background brightness | |
| | Normal | | and is recommended for FPS games. | |
| | Strong | | | |
| | Strongest | | | |
| | A.I. | | | |
| Al Vision | OFF | | Al Vision enhances image quality by optimizing | |
| | ON | | the contrast of images and background brightness. | |
| | | | Activating Al Vision will affect: | |
| | | | Affected Function Function Status | |
| | | | » Night Vision Unable to select | |
| Refresh Rate | Location | Left Top | Location is adjustable in OSD Menu. Press the | |
| | | Right Top | OK Button to confirm and apply your Refresh Rate Location. | |
| | | Left Bottom | This monitor follows and works at the Operating | |
| | | Right Bottom | System's preset Screen Refresh Rate. | |
| | | Customize | | |
| | OFF | | | |
| | ON | | | |
| Alarm Clock | Location | Left Top | After setting the time, press the OK Button to | |
| | | Right Top | activate the timer. • Users have to manually restore their preset | |
| | | Left Bottom | Alarm Clock after any AC power loss and | |
| | | Right Bottom | reconnection. | |
| | Customize | | | |
| | OFF | | | |
| | 15:00 | 00:01 ~ 99:59 | | |
| | 30:00 | | | |
| | 45:00 | | | |
| | 60:00 | | | |

| 1st Level Menu | 2nd/3rd Level Menu | Description | | |
|----------------|--------------------|--|--|--|
| Adaptive-Sync | OFF ON | Adaptive-Sync prevents screen tearing. Activating Adaptive-Sync will affect: | | |
| | | Affected Function Function Status » PIP/PBP » Optix Scope » Screen Size 1:1/24.5"/27" Set to Auto | | |
| DSC | OFF ON | Users can toggle DSC (Display Stream Compression) on/off. For more DSC timing information, please check Preset Display Modes for DSC On/Off timing tables. Activating DSC will affect: | | |
| | | Affected Function Function Status PIP/PBP Unable to select | | |
| НДМІ™ 2.1 | PC PC | To reach resolution of 2160P@30Hz/60Hz/120Hz, user have to set HDMI™ 2.1 to Console. | | |

Professional

| 1st Level Menu | 2nd Level Menu | Description |
|----------------|----------------|--|
| Pro Mode | Eco | Use Up or Down Button to select and preview mode effects. |
| | User | Press the OK Button to confirm and apply your mode |
| | Anti-Blue | type. The default setting "Eco" mode meets the |
| | Movie | requirements of TÜV Rheinland's "Low Blue Light" standard and Eyesafe certification. |
| | Office | Activating sRGB, Adobe RGB, Display P3 will affect: |
| | sRGB | Affected Function Function Status |
| | SKOD | » Color Temperature |
| | Adobe RGB | » Low Blue Light Unable to select |
| | Display P3 | » Contrast |

| 1st Level Menu | 2nd Level Menu | Description |
|-------------------|----------------|--|
| Low Blue Light | OFF | Low Blue Light protects your eyes against blue light. |
| | ON | When enabled, Low Blue Light adjusts the screen color temperature to a more yellow glow. |
| | | When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light. |
| | | This monitor is a Low Blue Light backlight monitor, it would decrease the blue light emitted without adjusting OSD function. |
| Image Enhancement | OFF | Image Enhancement enhances image edges to improve |
| | Weak | their acutance. |
| | Medium | |
| | Strong | |
| | Strongest | |

Image

| 1st Level Menu | 2nd/3rd Level Menu | | Description | | |
|-------------------|--------------------|------------------------|---|---|------------------------|
| Brightness | 0-100 | | Properly adjust Brightness according to the surrounding lighting. | | |
| Contrast | 0-100 | | • 1 | Properly adjust Contras | t to relax your eyes. |
| Sharpness | 0-5 | | Sharpness improves clarity and details of images. | | rity and details of |
| Color Temperature | Cool | | | Jse Up or Down Button | to select and preview |
| | Normal | | | mode effects. Press the OK Button to | confirm and apply your |
| | Warm Customization | | | mode type. | commini and apply your |
| | | R (0-100) | | Jsers can adjust Color | Temperature in |
| | | G (0-100) |] ' | Customization mode. | |
| | B (0-100) | | | | |
| Screen Size | Auto | | Users can adjust Screen Size in any mode, ar | | |
| | 4:3 | | resolution and any screen refresh rate. | | |
| | 16:9 | , | Activating Screen Size 1:1 wi Affected Function Fu | | |
| | 21:9 | | | | Function Status |
| | 1:1 | - | ⊣ ', ' | | |
| | | | | Set to OFF | |
| | 24.5" | | | » Optix Scope | |
| | 27" | | | | |
| DisplayHDR | True Black 400 | | Users can set the DisplayHDR to True Black | | |
| Peak 1000 nits | | 400 or Peak 1000 nits. | | | |

Input Source

| 1st Level Menu | 2nd Level Menu | Description |
|----------------|----------------|---|
| HDMI™ 1 | | Users can adjust Input Source in any mode. |
| HDMI™ 2 | | |
| DP | | |
| Туре С | | |
| Auto Scan | OFF | Users can use the Navi Key to select Input Source at |
| | ON | below status: While "Auto Scan" is set to "OFF" with the monitor at power saving mode; While "No Signal" message box is shown on the monitor. |

PIP/PBP

| 1st Level Menu | 2nd/3rd Level Menu | | D | escription | | |
|----------------|-----------------------------|--------------|--|---|-------------------------------|--|
| OFF | OFF | | • | PIP (Picture in Picture) allows users to | | |
| PIP | Source | HDMI™ 1 | one screen. Une program is displayed or | | | |
| | | HDMI™ 2 | | | | |
| | | DP |]. | | | |
| | | Type C | PBP (Picture by Picture) is a similar feat displays two input sources side-by-side | | | |
| | PIP Size | Small | ١. | screen. Display Switch allows use | rs to switch hatwaan | |
| | | Medium | | primary and secondary in | | |
| | | Large | • | If there is only one signal and Audio Switch will be o | | |
| | Location | Left Top | | Users can adjust the ratio | | |
| | | Right Top | | switching Mode 1/2/Cust | omize. | |
| | | Left Bottom | • | Activating PIP/PBP will af | | |
| | | Right Bottom | Right Bottom Affected Fu | | Function Status | |
| | | Customize | stomize ' ' | » Adaptive-Sync» Optix Scope | Set to OFF | |
| | Display Swi | tch | | » DisplayHDR | Unable to select | |
| | Audio Switc | h | | » HDMI™ 2.1 | Unable to select | |
| PBP | Mode 1 | | | » HDMI™ CEC | Set to OFF & unable to select | |
| | Mode 2 | | | » PIP: Screen Size 1:1 | Set to Auto & | |
| | Customize | | | » PBP: Screen Size | unable to select | |
| | Source 1 | HDMI™ 1 | | » PIP: Screen Size | Set to Auto | |
| | | HDMI™ 2 | | 24.5"/27" | Set to Auto | |
| | | DP | | | | |
| | | Type C | | | | |
| | Source 2 | HDMI™ 1 | | | | |
| | | HDMI™ 2 | | | | |
| | | DP | | | | |
| | | Type C | | | | |
| | Display Switch Audio Switch | | | | | |
| | | | | | | |

Navi Key

| 1st Level Menu | 2nd Level Menu | Description |
|----------------|-----------------|---|
| Up | OFF | All Navi Key items can be adjusted via OSD Menus. |
| Down | Brightness | |
| Left | Game Mode | |
| Right | Smart Crosshair | |
| | Alarm Clock | |
| | Input Source | |
| | PIP/PBP Mode | |
| | Refresh Rate | |
| | Info. On Screen | |
| | Night Vision | |
| | Optix Scope | |
| | KVM | |

Settings

| 1st Level Menu | 2nd Level Menu | Description | | | | |
|----------------|------------------------------|---|--|--|--|--|
| Language | 繁體中文 | Users have to press the OK Button to confirm and | | | | |
| | English | apply the Language setting. Language is an independent setting. Users' own | | | | |
| | Français | language setting will override the factory default. | | | | |
| | Deutsch | When users set Reset to Yes, Language will not be changed. | | | | |
| | Italiano | | | | | |
| | Español | | | | | |
| | 한국어 | | | | | |
| | 日本語 | | | | | |
| | Русский | | | | | |
| | Português | | | | | |
| | 简体中文 | | | | | |
| | Bahasa Indonesia | | | | | |
| | Türkçe | | | | | |
| | (More languages coming soon) | | | | | |
| Transparency | 0~5 | Users can adjust Transparency in any mode. | | | | |
| OSD Time Out | 5~30s | Users can adjust OSD Time Out in any mode. | | | | |
| Power Button | OFF | When set to OFF, users can press the power button to turn off the monitor. | | | | |
| | Standby | When set to Standby, users can press the power button to turn off the panel and backlight. | | | | |

| 1st Level Menu | 2nd Level Menu | Description |
|------------------|----------------|---|
| Info. On Screen | OFF | The information of the monitor status will be shown |
| | ON | on the right side of the screen. |
| HDMI™ CEC | OFF | HDMI™ CEC (Consumer Electronics Control) supports Sony PlayStation®, Nintendo® Switch™, |
| | ON | Xbox Series X S consoles and various audio-visual devices that are CEC-capable. |
| | | If HDMI™ CEC is set to 0N: |
| | | The monitor will automatically power on when the CEC device is turned on. |
| | | The CEC device will enter power saving mode when the monitor is turned off. |
| | | When Sony PlayStation®, Nintendo® Switch™, or Xbox Series XIS console is connected, Game Mode and Pro Mode will be automatically set to default Eco mode and can be adjusted to users' preferred modes later. |
| Type C PD Charge | OFF | Type C PD Charge enables users to charge their |
| | ON | devices through a USB Type-C connector, which can deliver up to 98W (20V/4.9A). |
| Power LED | OFF | Users can toggle the Power LED on/off. |
| | ON | During the Panel Protect process, the power LED indicator will blink orange until the process is complete. |
| Reset | YES | Users can Reset and restore settings to original |
| | NO | OSD Default in any mode. |

MSI OLED Care

| 1st Level Menu | 2nd/3rd Level Menu | Description | | |
|----------------|--------------------|--|--|--|
| Pixel Shift | Slow | Pixel Shift moves the pixels of your screen at | | |
| | Normal | regular intervals to reduce the possibility of screen burn-in or image retention. | | |
| | Fast | j | | |
| Panel Protect | | To maintain panel image quality, panel protect function will automatically activate when monitor using over 4 hours. | | |
| | | This protect function may take several minutes to complete. | | |
| | | The power indicator will blink orange color until process done. | | |
| | | During process executing, please do not unplug the power cord from monitor. | | |
| | | During process executing, press power button again to cancel this function. | | |

| 1st Level Menu | 2nd/3rd Level M | enu | De | scriptio | n | | |
|-------------------------|-------------------|---------|--|---|--|---|--|
| Protect Notice | Auto Usage 16 hrs | | When set to Auto, Protect Notice will pop up when the panel exceeds 4 hours of cumulative usage. | | | 4 hours of cumulative | |
| | | | | pop up v | | s, Protect Notice will acceeds 16 hours of | |
| | | | • | | anel Protect is int vill pop up upon n | terrupted, Protect lext power-up. | |
| Static Screen Detection | OFF | | • | If Static | Screen Detection | is set to ON: | |
| | ON | | | perio | detecting static ds of time, the mo tness to prevent | | |
| | | | | | | visuals, the monitor rightness setting. | |
| | Starting in | 50 Sec | | | | ne a static image | |
| | 100 S | | remains on the screen. | | | | |
| | Time required | 120 Sec | | Time required specifies the time for bright | | | |
| | 240 Sec | | reduction after detecting a static image for 50/100 seconds. | | | | |
| | | | The brightness reduction level depends on the setting of Reducing Level. | | | | |
| | Reducing Level | 1-7 | Users can select a level for brightness reduction. | | | or brightness | |
| | | | Reducing effect depends on Brightness/ DisplayHDR setting. | | | | |
| Multi Logo Detection | OFF | | This function helps prevent image sticking phenomenon. When set to ON, brightness | | | | |
| | ON | | | reduction of multi logo areas will kick in are detected. | | reas will kick in if logos | |
| | | | • | | | k when the monitor is Refresh Rate) content. | |
| | | | | VRR* | VRR Content** | Multi Logo Detection | |
| | | | | ON | YES | Set to OFF & Unable to select | |
| | | | | ON | NO | - Adjustable | |
| | | r | | OFF | N0 | _ | |
| | Reducing Level | 1-2 | | Users ca reductio | an select a level f in. | or brightness | |
| | | | Reducing effect depends on Brightness/ DisplayHDR setting. | | | | |

| 1st Level Menu | 2nd/3rd Level M | enu | De | Description | | | |
|--------------------|--------------------|-----|--|--|---------------|-------------------------------|--|
| Taskbar Detection | OFF ON | | • | This function helps prevent image sticking phenomenon. When set to ON, brightness reduction of taskbar areas will kick in if taskbars are detected. This function will not work when the monitor receiving VRR (Variable Refresh Rate) conten | | | |
| | | | | VRR* VRR Content** Taskbar Detection | | | |
| | | | | ON | YES | Set to OFF & Unable to select | |
| | | | | ON | N0 | Adjustable | |
| | | | | 0FF | N0 | Aujustabie | |
| | Reducing Level 1-3 | | | Users can select a level for brightness reduction. Reducing effect depends on Brightness/DisplayHDR setting. | | | |
| Boundary Detection | OFF ON | | This function helps prevent image sticking phenomenon. When set to ON, brightness reduction of boundary areas will kick in if boundaries, such as letters, pillars and ver lines, are detected. This function will not work when the monit receiving VRR (Variable Refresh Rate) cont | | | | |
| | | | | VRR* | VRR Content** | Boundary Detection | |
| | | | | ON | YES | Set to OFF & Unable to select | |
| | | | | ON | N0 | Adimatable | |
| | | | | OFF | N0 | Adjustable | |
| | Reducing Level 1-3 | | Users can select a level for brightness reduction. Reducing effect depends on Brightness/DisplayHDR setting. | | | | |
| OLED Panel Info. | | | This field shows the information of MSI OLED Care. | | | | |

^{*} HDMITM VRR (Variable Refresh Rate) synchronizes with Adaptive-Sync (ON/ OFF). For VRR ON/OFF status, please check Adaptive-Sync.

^{**} When VRR is set to ON, the monitor scaler will detect whether the graphics card is sending VRR content.

Specifications

| Monitor | MPG 341CQPX QD-OLED | | | |
|-----------------------------|-----------------------------------|--|--|--|
| Size | 34.18 inch | | | |
| Curvature | 1800R | | | |
| Panel Type | QD-OLED | | | |
| Resolution | 3440 x 1440 (UWQHD) | | | |
| Aspect Ratio | 21:9 | | | |
| Brightness | • Typical SDR: 250 nits | | | |
| | • Peak HDR: 1000 nits | | | |
| Contrast Ratio | 1500000:1 | | | |
| Refresh Rate | 240Hz | | | |
| Response Time | 0.03ms (GtG) | | | |
| 1/0 | HDMI™ Connector x 2 | | | |
| | DisplayPort x 1 | | | |
| | USB Type-C Port x 1 | | | |
| | USB 2.0 Type-A Port x2 | | | |
| | • USB 2.0 Type-B Upstream Port x1 | | | |
| | • Headphone Jack x1 | | | |
| View Angles | 178°(H) , 178°(V) | | | |
| DCI-P3*/ sRGB | 99.3%/ 139.1% | | | |
| Surface Treatment | Anti-Reflection | | | |
| Display Colors | 1.07B (10 bits) | | | |
| Monitor Power Options | 100-240V~, 50/60Hz 3.5A | | | |
| | Power On < 250W | | | |
| Power Consumption (Typical) | Standby < 0.5W | | | |
| (1) (1) | Power Off < 0.3W | | | |
| Adjustment (Height) | 0 ~ 100mm | | | |
| Adjustment (Tilt) | -5° ~ 20° | | | |
| Adjustment (Swivel) | -30° ~ 30° | | | |
| Kensington Lock | Yes | | | |

| Monitor | | MPG 341CQPX QD-OLED | | |
|----------------|-----------|--|--|--|
| VESA Mounting | | • Plate Type: 100 x 100 mm | | |
| | | • Screw Type: M4 x 10 mm | | |
| | | • Thread Diameter: 4 mm | | |
| | | • Thread Pitch: 0.7 mm | | |
| | | Thread Length: 10 mm | | |
| Dimension (W x | D x H) | 812 x 318 x 427 mm | | |
| Weight | Net | 8.9 kg | | |
| weight | Gross | 12.7 kg | | |
| Environment | Operating | • Temperature: 0°C to 40°C | | |
| | | Humidity: 20% to 90%, non-condensing | | |
| | | • Altitude: 0 ~ 5000m | | |
| | Storage | • Temperature: -20°C to 60°C | | |
| | | • Humidity: 10% to 90%, non-condensing | | |

^{*} Based on CIE1976 test standards.

Preset Display Modes

1mportant

- All information is subject to change without prior notice.
- HDMI™ VRR (Variable Refresh Rate) synchronizes with Adaptive-Sync (ON/ OFF). For VRR ON/OFF status, please check Adaptive-Sync.

| Class dans d | Standard Resolution | | HDMI™ 2.1 - PC + DSC On | | | |
|--------------|---------------------|--------|-------------------------|----|-------|--|
| Standard | | | HDMI™ | DP | USB-C | |
| QHD | 2560x1440 | @60Hz | ٧ | ٧ | V | |
| | | @120Hz | ٧ | ٧ | V | |
| WQHD | 3440x1440 | @50Hz | V | | | |
| | | @60Hz | ٧ | V | V | |
| | | @100Hz | ٧ | ٧ | V | |
| | | @120Hz | ٧ | ٧ | V | |
| | | @165Hz | ٧ | ٧ | V | |
| | | @240Hz | V | ٧ | V | |
| Video Timing | 720P | | V | ٧ | V | |
| Resolution | 1080P | @60Hz | V | V | V | |
| | | @120Hz | V | V | V | |
| | HDMI™ VRR f | or PS | V | | | |

| Chandand | Desclution | | HDMI™ 2.1 - | PC + DSC Off | |
|--------------|-------------|--------|-------------|--------------|-------|
| Standard | Resolution | | HDMI™ | DP | USB-C |
| QHD | 2560x1440 | @60Hz | ٧ | ٧ | V |
| | | @120Hz | ٧ | ٧ | V |
| WQHD | 3440x1440 | @50Hz | ٧ | | |
| | | @60Hz | ٧ | ٧ | ٧ |
| | | @100Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | | @165Hz | ٧ | ٧ | ٧ |
| | | @240Hz | ٧ | | |
| Video Timing | 720P | | ٧ | ٧ | ٧ |
| Resolution 1 | 1080P | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | HDMI™ VRR f | or PS5 | ٧ | | |

| 6 | | | HDMI™ 2.1 | l - Console + | DSC On |
|--------------|-------------|--------|-----------|---------------|--------|
| Standard | Resolution | | HDMI™ | DP | USB-C |
| QHD | 2560x1440 | @60Hz | ٧ | V | V |
| | | @120Hz | ٧ | V | V |
| WQHD | 3440x1440 | @50Hz | ٧ | | |
| | | @60Hz | ٧ | V | ٧ |
| | | @100Hz | ٧ | V | V |
| | | @120Hz | V | V | V |
| | | @165Hz | ٧ | V | V |
| | | @240Hz | V | V | V |
| Video Timing | 720P | | ٧ | V | V |
| Resolution | 1080P | @60Hz | ٧ | V | V |
| | | @120Hz | V | V | V |
| | 2160P | @30Hz | V | | |
| | | @60Hz | V | | |
| | | @120Hz | V | | |
| | 2560x1080P | @60Hz | ٧ | V | V |
| | | @120Hz | V | V | V |
| | HDMI™ VRR f | or PS5 | V | | |

| Chandand | Decelution | | HDMI™ 2.1 - | Console + DSC | Off |
|----------|------------|--------|-------------|---------------|-------|
| Standard | Resolution | | HDMI™ | DP | USB-C |
| QHD | 2560x1440 | @60Hz | ٧ | ٧ | V |
| | | @120Hz | ٧ | ٧ | V |
| WQHD | 3440x1440 | @50Hz | ٧ | | |
| | | @60Hz | ٧ | ٧ | V |
| | | @100Hz | ٧ | ٧ | V |
| | | @120Hz | ٧ | ٧ | V |
| | | @165Hz | ٧ | ٧ | V |
| | | @240Hz | ٧ | | |

| Chandand | David di | | HDMI™ 2.1 - | Console + DSC | Off |
|--------------|--------------|--------|-------------|---------------|-------|
| Standard | Resolution | | HDMI™ | DP | USB-C |
| Video Timing | 720P | | ٧ | ٧ | V |
| Resolution | 1080P | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | 2160P | @30Hz | ٧ | | |
| | | @60Hz | ٧ | | |
| | | @120Hz | ٧ | | |
| | 2560x1080P | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | HDMI™ VRR fo | or PS5 | ٧ | | |

| Chandand | Resolution | | Standard Mode | | |
|--------------|-------------------|--------|---------------|----|-------|
| Standard | | | HDMI™ | DP | USB-C |
| QHD | 2560x1440 | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| WQHD | 3440x1440 | @50Hz | ٧ | | |
| | | @60Hz | ٧ | ٧ | ٧ |
| | | @100Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | | @165Hz | ٧ | ٧ | ٧ |
| | | @240Hz | ٧ | ٧ | ٧ |
| Video Timing | 720P | | ٧ | ٧ | ٧ |
| Resolution | 1080P | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | 2160P | @30Hz | ٧ | | |
| | | @60Hz | ٧ | | |
| | | @120Hz | ٧ | | |
| | 2560x1080P | @60Hz | ٧ | ٧ | ٧ |
| | | @120Hz | ٧ | ٧ | ٧ |
| | HDMI™ VRR for PS5 | | ٧ | | |

| Clarida de | Resolution | | PIP Mode (Not Support HDR) | | |
|----------------------------|------------|--------|----------------------------|----|-------|
| Standard | | | HDMI™ | DP | USB-C |
| Full HD | 1920x1080 | @60Hz | ٧ | V | V |
| QHD | 2560x1440 | @60Hz | ٧ | V | V |
| | | @120Hz | ٧ | V | V |
| WQHD | 3440x1440 | @50Hz | ٧ | | |
| | | @60Hz | ٧ | V | V |
| Video Timing Resolution | 720P | | ٧ | V | V |
| | 1080P | @60Hz | ٧ | V | V |
| | | @120Hz | ٧ | V | V |
| | 2160P | @30Hz | ٧ | V | |
| | | @50Hz | V | V | |
| | | @60Hz | V | V | |

| Standard | Resolution | | PBP Mode 1 (Not Support HDR) | | | |
|-----------------------------|------------|-------|------------------------------|----|-------|--|
| | | | HDMI™ | DP | USB-C | |
| Video Timing Resolution | 720P | | V | V | V | |
| Used for PBP Full Screen | 2560x1440 | @60Hz | ٧ | ٧ | ٧ | |
| | 880x1440 | @60Hz | ٧ | ٧ | ٧ | |

| Standard | Resolution | | PBP Mode 2/ Customize (Not Support HDR) | | |
|-----------------------------|------------|-------|--|----|-------|
| | | | HDMI™ | DP | USB-C |
| Video Timing Resolution | 720P | | V | V | V |
| Used for PBP Full Screen | 1720x1440 | @60Hz | V | V | V |

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.

TÜV Rheinland Flicker Free Certification

- TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.
- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

Regulatory Notices

CE Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, \mathbb{N}^2 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS


As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- · Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.





 Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

MSI 微星





Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.