

WORKFLOW BATTERY CASE QUICK GUIDE

PACKAGE CONTENTS · Rugged Workflow case

- 3.200mAh battery pack
- Hand strap

SPECIFICATIONS

- · Drop Protection: 12ft (4m), MIL-STD 810G · Speaker protection: Non-woven mesh acoustic vents
- · Hand strap: Adjustable, removable
- · Battery capacity: 3,200mAh (12.3Wh) Lithium Polymer
- · Battery charging input: 5-Watt, 5V/1A max
- · Battery wireless charging output: 5-Watt (Wireless)
- Wireless Status Indicator: 1x Blue I FD
- · Battery Indicator: 4x White LED
- Weight: 190 grams (6.7oz)
- Dimensions: 153.4x79.2x24.4mm (6x3.1x0.96in)
- Storage Temperature: 50°F to 75°F (10°C to 24°C).
- Charging Temperature: 40°F to 95°F (5°C to 34°C).
- Operating Temperature: 40°F to 95°F (5°C to 35°C).

CASE INSTALLATION

- Place the case on a flat surface.
- 2. Align your device's camera with the camera opening on the case.
- 3. Insert your device at an angle, starting with the left side (volume button side).
- 4.Let your device rest on the bottom of the case, then
- gently press it down into the case. 5. Press around all the edges to ensure your device is securely installed in the case.

BATTERY PACK INSTALLATION

- To remove the battery pack, push the battery release button up and pull the battery pack away from the case.
 To install the battery pack, insert it at an angle, starting
- from the bottom.

 3. Let the battery pack rest on the bottom of the case, then gently press the top down until it snaps into place.

BATTERY PACK CHARGING

Use a USB-C cable (not included) to charge the battery pack through the USB-C port located at the bottom of the battery pack. Alternatively, you can charge the battery pack using the optional Workflow Charging Docks.

For safety information, please refer to the Safety and Usage Guidelines at the end of this manual.

BATTERY PACK OPERATION

Press the battery button once to power on the battery pack and enable device charging. Press once again to check the battery charge status.

Press the battery button twice to power off the battery pack.

For additional safety information, please refer to the Safety and Usage Guidelines at the end of this manual.

LED INDICATORS

- Blue LED Wireless charging indicator. Solid if
- charging
- White LED (4) Battery charge status indicators
- 10%-25% charge26%-50% charge
- 51%-75% charge
- 75%-100% charge

1 YEAR LIMITED WARRANTY

For warranty terms and conditions visit urbanarmorgear.com/warranty Urban Armor Gear, LLC 1601 Alton Parkway, Suite C, Irvine, CA 92606 Made in China

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver. $% \label{eq:equipment} % \la$

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
ICES-003 CLASS B NOTICE - AVIS NMB-003, CLASSE B

This device complies with Part 15 of the FCC Rules.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. This device

conforme à la norme NMB-003 du Canada. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

DECLARATION OF CONFORMITY

Hereby, Urban Armor Gear, LLC declares that the wireless charging device is in compliance with Directives 2014/53/EU & 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address:

https://www.urbanarmorgear.com/EU-DOC

Frequency band(S)	110 kHz - 205 kHz
Maximum radio-frequency power transmitted	0.67 dBua/m at 3m

WARNING: This Product can expose you to chemicals including Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. wwwP65Warnings.ca.gov

*Apple® and iPhone® are registered trademarks of the Apple Inc.

PÄTENTS PENDING ©2024 URBAN ARMOR GEAR. All rights reserved. URBAN ARMOR GEAR® and UAG® logo are registered trademarks of URBAN ARMOR GEAR. LLC., Laguna Niguel, CA. All other trademarks and registered trademarks are the property of their respective owners.

WARNING: Under certain circumstances, lithium-ion batteries can present a risk of fire or explosion during charging, storage and use, that could result in personal injury, including death and/or property damage.

SAFETY AND USAGE GUIDELINES

Urban Armor Gear (UAG) battery packs and chargers are designed to provide uninterrupted power for mobile phones and devices. While UAG battery packs are built to be durable and rugged, it is important that they be charged, stored and used safely. Like all lithium-ion batteries, UAG battery packs store a large amount of energy compared to traditional alkaline batteries. It is

important for users to understand the potential risks and precautions, and to follow these safety guidelines and instructions associated with lithium-ion batteries. Users must conduct a thorough inspection of a battery pack and charger before each use to operate them safely.

Product Instructions

 Always adhere to the instructions regarding charging, storage and use of battery packs and chargers provided with the devices and available on UAG's website at https://enterprise.urbanarmorgear.com/manuals
 Operate the battery packs and chargers only within the specifications provided by the manufacturer.

Environmental Conditions

- Avoid charging, storing or using battery packs or chargers in environments with extreme temperatures, high humidity or direct sunlight.
 - Battery packs and chargers should be stored in a controlled environment, ideally between 50°F to 75°F(10°C to 24°C).
- Do not charge battery packs or charge devices in temperatures below 40°F (5°C) or above 95°F (35°C) to prevent damage.
 - ${\scriptstyle \circ}$ Storage Temperature: 50°F to 75°F (10°C to 24°C).
 - Charging Temperature: 40°F to 95°F (5°C to 34°C).
 Operating Temperature: 40°F to 95°F (5°C to 35°C).
- Keep battery packs and devices away from open flames, flammable or combustible materials or any high-heat source.
- · Do not submerge the battery pack or charger in water.
- Ensure that the battery pack is dry before attaching to a device or charger.

Charging Location and Process

- Avoid leaving a battery pack or device charging for longer than necessary.
- Charged battery packs should not be stored in a charger.
- Do not leave battery packs, devices or chargers unattended while charging.
- Avoid contact between battery packs or chargers and metal objects to prevent short-circuiting.
- Ensure that the charging area is clean and free of any debris before use.

 Depart the second better a police of device on flower black.

 The second better a police of the second black of the se
- Do not charge battery packs or devices on flammable surfaces, including wood or fabric.
- Do not charge battery packs or devices in an area that includes combustible materials, including loose paper or flammable liquids and gasses.
- Do not allow wires, cables or other materials to rest on top of chargers.

Battery and Charger Compatibility

- Use only the chargers provided with or approved by the manufacturer for charging your battery pack or device.
- The charger provided with or approved for use with your battery pack is specifically designed to be used with that battery pack; do not substitute other batteries or chargers for use with each other.

Operation and Maintenance Guidelines

- Do not modify, disassemble, puncture, cut, crush, or incinerate battery packs or chargers.
- Do not intentionally cause a battery pack, device or charger to short circuit.

- Defective or damaged battery packs, devices or chargers should not be used under any circumstances.
- Do not use battery packs, devices or chargers that are damaged or have visible cracks, dents, holes or tears.
- If you suspect a battery pack, device or charger is defective or damaged, do not attempt to use it.
- If a battery pack, device or charger overheats, or you notice an odor or smoke, change in shape/color, leaking or odd noises from a device discontinue use and disconnect from power sources immediately.

Temperature Changes During Operation

- During normal operation, it is common for a battery pack or an attached device to feel warm to the touch. This warmth may increase when the device is being charged and used simultaneously.
- Should the battery pack show signs of overheating, such as emitting heat that is uncomfortable to the touch (typically exceeding 1189° or 48°C), immediately disconnect the battery pack from any device and let it cool down before attempting to charge it again. For optimal performance and safety, please wait until the battery pack has returned to a normal temperature before resuming charging of the battery pack or your device.

Transportation and Shipping

 Transportation or shipping of lithium-ion batteries is subject to laws and regulations. Users should ensure that they are complying with all applicable laws and regulations before transporting or shipping lithium-ion batteries.

PROPER DISPOSAL AND RECYCLING OF BATTERIES

WARNING: Disposing of batteries in the trash or regular recycling is dangerous and illegal. Disposing of batteries in a fire is strictly prohibited and may risk an explosion. Batteries should not be disassembled, crushed, punctured, heated, burned, or reused. For detailed information on safe disposal and recycling, please visit call2recycle.org or refer to local regulations regarding battery recycling.

UAG DISCLAIMS ANY RESPONSIBILITY FOR DAMAGES OR INJURIES RESULTING FROM THE IMPROPER USE OR MISHANDLING OF LITHIUM-ION BATTERIES AND CHARGERS. USE OF BATTERIES AND CHARGERS IS AT YOUR OWN RISK.



No washing



No metal objects on the surface



No knockina









Multi Language Manual