

# **MAG Series**

**LCD Monitor** 

MAG 325CQF (3DC1)

User Guide

### **Contents**

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	6
Connecting the Monitor to PC	8
OSD Setup	9
Navi Key	9
Hot Key	9
OSD Menus	10
Gaming	11
Professional	13
Image	14
Input Source	14
PIP/PBP	15
Navi Key	16
Settings	16
Specifications	18
Preset Display Modes	20
Troubleshooting	22
Safety Instructions	23
TÜV Rheinland Certification	25
Regulatory Notices	26

#### Revision

V1.0, 2024/10

### **Getting Started**

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

### **Package Contents**

Monitor	MAG 325CQF	
Documentation	Quick Start Guide	
	Stand	
	Stand Base	
Accessories	VESA Wall Mount Screws	
	Power Cord	
	External Power Supply	
Cables	DisplayPort Cable (Optional)	




# Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country and model.
- The included power cord is exclusively for this monitor and should not be used with other products.

### **Installing the Monitor Stand**

- 1. Leave the monitor in its protective packaging. Align and gently push the stand bracket towards the monitor groove until it locks in place.
- 2. Align and gently push the cable organizer towards the stand until it locks in place.
- 3. Align and gently push the base towards the stand until it locks in place.
- **4.** Make sure the stand assembly is properly installed before setting the monitor upright.



### ⚠

#### 

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any
  mechanical damages to the product including removal of the polarizing film may
  affect the warranty!




### **Adjusting the Monitor**


This monitor is designed to maximize your viewing comfort with its adjustment capabilities.



• Avoid touching the display panel when adjusting the monitor.



#### **Monitor Overview**



**Power LED** 1 Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode. Power Button & Navi Key Cable Organizer Power Jack 5 Headphone Jack **DisplayPort** 6 Supports 2560x1440@180Hz as specified in DisplayPort 1.4a. 7 HDMI **HDMI™** Connector Supports HDMI<sup>™</sup> CEC, 2560x1440@144Hz as specified in HDMI<sup>™</sup> 2.0b. **Important** To ensure optimal performance and compatibility, please use only HDMI™ cables certified with the official HDMI™ logo when connecting this monitor. For more information, please visit https://www.hdmi.org/resource/cables. H⊅mi™ 8 **HDMI™** Connector Supports 2560x1440@144Hz as specified in HDMI™ 2.0b. **Important** To ensure optimal performance and compatibility, please use only HDMI™ cables certified with the official HDMI<sup>™</sup> logo when connecting this monitor. For more information, please visit https://www.hdmi.org/resource/cables. **USB Type-C Port** 9 This port supports DisplayPort Alternate (DP Alt) Mode and up to 5V/3A [15W] power delivery. It only carries video signals and doesn't support data transmission function. **Important** 

Your USB-C signal source and cable must support DisplayPort Alternate


Mode to enable video output to the monitor.

10

**Kensington Lock** 

### Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Assemble the external power supply & power cord. (Figure A)
- **4.** Connect the external power supply to the monitor power jack. (Figure B)
- **5.** Plug the power cord into the electrical outlet. (Figure C)
- **6.** Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto detect the signal source.



### **OSD Setup**


This chapter provides you with essential information on OSD Setup.



All information is subject to change without prior notice.

### **Navi Key**

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



#### Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


#### Press (OK):

- launching the On-Screen Display (OSD)
- entering submenus
- · confirming a selection or setting

### **Hot Key**

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

### **OSD Menus**





# Important

The following settings will be grayed out when HDR signals are received:

- Night Vision
- MPRT
- Low Blue Light
- HDCR
- Al Vision

- Brightness
- Contrast
- Color Temperature
- PIP/PBP

## Gaming

1st Level Menu	2nd/3rd Level Menu	Description	
Game Mode	User FPS Racing RTS RPG	Use Up or Down Button mode effects. Press the OK Button to mode type. Game Mode defaults to HDR modes.	confirm and apply your
Night Vision	OFF Normal Strong Strongest A.I.	This function optimizes and is recommended fo	
Al Vision	OFF ON	Al Vision enhances images a brightness.     Activating Al Vision will      Affected Function     Night Vision     Brightness     HDCR     MPRT	and background
Response Time	Normal Fast Fastest	Setting to Fastest will re response time and help when playing very fast g	improve blurred images
MPRT	OFF ON	MPRT is available when 85 Hz.     Activating MPRT will aff     Affected Function     Brightness     Response Time	
		» HDCR » Adaptive-Sync » PIP/PBP » Al Vision	Set to 0FF
		» Screen Size	Set to Auto

1st Level Menu	2nd/3rd Leve	el Menu	Description
Refresh Rate	Location	Left Top	Location is adjustable in OSD Menu. Press the
		Right Top	OK Button to confirm and apply your Refresh Rate Location.
		Left Bottom	This monitor follows and works at the Operating
		Right Bottom	System's preset Screen Refresh Rate.
		Customize	
	OFF		
	ON		
Alarm Clock	Location	Left Top	After setting the time, press the OK Button to
		Right Top	activate the timer.  • Users have to manually restore their preset
		Left Bottom	Alarm Clock after any AC power loss and
		Right Bottom	reconnection.
		Customize	
	OFF		
	15:00	00:01 ~ 99:59	
	30:00		
	45:00		
	60:00		
Smart Crosshair	Icon	None	Through Al algorithm, this function enhances the
	Color		visibility of in-game crosshair.      Users can select the color and position of the crosshair.
		Red	
		Auto	
	Position		
	Reset		

1st Level Menu	2nd/3rd Level Menu	De	scription	
Adaptive-Sync	OFF ON	Adaptive-Sync prevents screen     Activating Adaptive-Sync will a		· ·
			Affected Function	Function Status
			» MPRT » PIP/PBP	Set to OFF
			» Screen Size 1:1	Set to Auto

### **Professional**

1st Level Menu	2nd Level Menu	Description			
Pro Mode	Eco	Use Up or Down Button to select and preview mode effects.			
	User	Press the OK Button to confirm and apply your mode			
	Anti-Blue	<ul> <li>type.</li> <li>Pro Mode defaults to Eco for SDR mode and User for</li> </ul>			
	Movie	HDR mode.			
	Office				
	sRGB				
Low Blue Light	OFF	Low Blue Light protects your eyes against blue light.     When enabled, Low Blue Light adjusts the screen color			
	ON	temperature to a more yellow glow.			
		When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light.			
HDCR	OFF	HDCR enhances image quality by increasing the			
	ON	<ul><li>contrast of images.</li><li>Activating HDCR will affect:</li></ul>			
		Affected Function Function Status			
		» Brightness Unable to select			
		» MPRT Set to 0FF			
MPRT	OFF	MPRT is available when the refresh rate is over 85 Hz.			
	ON	Activating MPRT will affect:			
		Affected Function Function Status			
		» Brightness Unable to select			
		» Response Time			
		» HDCR			
		» Adaptive-Sync Set to OFF			
		» PIP/PBP  » Al Vision			
		» Al Vision  » Screen Size Set to Auto			
		35.15.75.25			

1st Level Menu	2nd Level Menu	Description
Image Enhancement	OFF	Image Enhancement enhances image edges to improve
	Weak	their acutance.
	Medium	
	Strong	
	Strongest	

### Image

1st Level Menu	2nd/3rd Level Me	nu	Description		
Brightness	0-100		Properly adjust Brightness according to the surrounding lighting.		
Contrast	0-100		•	Properly adjust Contrast	to relax your eyes.
Sharpness	0-5		Sharpness improves clarity and details of images.		rity and details of
Color Temperature	Cool			Use Up or Down Button	to select and preview
	Normal			mode effects. Press the OK Button to c	confirm and apply your
	Warm			mode type.	onnin in and apply your
	Customization	R (0-100)		Users can adjust Color T	emperature in
	G (0-10		Customization mode.		
		B (0-100)	]		
Screen Size	Auto			Users can adjust Screen	, , ,
	4:3		resolution and any screen refresh rate.  • Activating Screen Size 1:1 will affect:		
	16:9		] •		
	16:10	,		Affected Function	Function Status
	1.1		1	» PIP/PBP	Set to OFF
			at	Important reen Size 1:1 refers to its original resolution	. This option is
			disabled when the monitor is set to its native resolution.		tor is set to its liative

# Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		Users can adjust Input Source in any mode.
НДМІ™ 2		
DP		
Type C		

Auto Scan	OFF	Users can use the Navi Key to select Input Source at
	ON	below status:     While "Auto Scan" is set to "OFF" with the monitor at power saving mode;     While "No Signal" message box is shown on the monitor.

### PIP/PBP

1st Level Menu	2nd/3rd Level Menu		Description		
0FF		PIP (Picture in Picture) allows users to			
PIP	Source	HDMI™ 1	simultaneously display multiple video sour one screen. One program is displayed on the		
		HDMI™ 2	screen at the same time a	as one or more other	
		DP	<ul><li>programs are displayed in</li><li>PBP (Picture by Picture) in</li></ul>		
		Type C	displays two input source		
	PIP Size	Small	screen.  • Display Switch allows use	urs to switch hetween	
		Medium	primary and secondary in		
		Large	If there is only one signal and Audio Switch will be a		
	Location	Left Top	Users can adjust the rational control of the c	•	
		Right Top	switching mode 1/2/Cus	tomize.	
		Left Bottom	Activating PIP/PBP will at	fect:	
		Right Bottom	Affected Function	Function Status	
		Customize » HDMI <sup>T</sup>	» HDMI™ CEC	Set to OFF & unable to select	
	Display Swit	ch	» Screen Size 1:1/16:10	Set to Auto & unable	
	Audio Switch	1		to select	
PBP	Mode 1				
	Mode 2				
	Customize				
	Source 1	HDMI™ 1			
		HDMI™ 2			
		DP			
		Type C			
	Source 2	HDMI™ 1			
		HDMI™ 2			
		DP	DP		
		Type C			
	Display Switch  Audio Switch				
			]		

## Navi Key

1st Level Menu	2nd Level Menu	Description
Up	0FF	All Navi Key items can be adjusted via OSD Menus.
Down	Brightness	
Left	Game Mode	
Right	Smart Crosshair	
	Alarm Clock	
	Input Source	
	PIP/PBP Mode	
	Refresh Rate	
	Info. On Screen	
	Night Vision	

## Settings

1st Level Menu	2nd Level Menu	Description
Language	繁體中文	Users have to press the OK Button to confirm and
	English	apply the Language setting.  • Language is an independent setting. Users' own
	Français	language setting will override the factory default.
	Deutsch	When users set Reset to Yes, Language will not be changed.
	Italiano	- changes.
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.
Info. On Screen	OFF	The information of the monitor status will be shown
	ON	on the right side of the screen.

1st Level Menu	2nd Level Menu	Description
HDMI™ CEC	OFF ON	HDMI™ CEC (Consumer Electronics Control) supports Sony PlayStation®, Nintendo® Switch™, Xbox Series XIS consoles and various audio-visual devices that are CEC-capable.      If HDMI™ CEC is set to ON:         The monitor will automatically power on when the CEC device is turned on.          The CEC device will enter power saving mode when the monitor is turned off.          When Sony PlayStation®, Nintendo® Switch™, or Xbox Series XIS console is connected, Game Mode and Pro Mode will be automatically set to
		default Eco mode and can be adjusted to users' preferred modes later.
Type C PD Charge	OFF	Type C PD Charge enables users to charge their
	ON	devices through a USB Type-C connector, which can deliver up to 15W (5V/3A).
Reset	YES	Users can Reset and restore settings to original
	NO NO	OSD Default in any mode.

# **Specifications**

Monitor		MAG 325CQF				
Size		31.5 inch				
Curvature		Curve 1000R				
Panel Type		Rapid VA				
Resolution		2560 x 1440 (WQHD)				
Aspect Ratio		16:9				
Brightness (ni	ts)	300				
Contrast Ratio		3500:1				
Refresh Rate		180Hz				
Response Time	е	• 1ms (MPRT)				
		• 0.5ms (GtG)				
1/0		HDMI™ Connector x 2				
		• DisplayPort x 1				
		USB Type-C Port x 1				
		Headphone Jack x1				
View Angles		178°(H) , 178°(V)				
DCI-P3*/ sRGE	3	96%/ 124%				
Surface Treatr	ment	Anti-glare				
Display Colors		1.07B, 10bits (8bits + FRC)				
Monitor Power	r Options	19.0V === 4.74A				
External Powe	er Supply**	Model: ADS-110CL-19-3 190090G				
Power Input		100~240V~, 50/60Hz, 1.5A Max				
Power Output		19.0V === 4.74A				
Adjustment (T	ilt)	-5° ~ 20°				
Kensington Lock		Yes				
VESA Mounting		• Plate Type: 100 x 100 mm				
		• Screw Type: M4 x 10 mm				
		Thread Diameter: 4 mm				
		• Thread Pitch: 0.7 mm				
		Thread Length: 10 mm				
Dimension (W	x D x H)	704.62 x 269.46 x 502.85 mm				
Weight	Net	6.4 kg				
Weight	Gross	8.6 kg				

Monitor		MAG 325CQF			
Environment	Operating	• Temperature: 0°C to 40°C			
		• Humidity: 20% to 90%, non-condensing			
		• Altitude: 0 ~ 5000m			
	Storage	• Temperature: -20°C to 60°C			
		• Humidity: 10% to 90%, non-condensing			

<sup>\*</sup> Based on CIE1976 test standards.

<sup>\*\*</sup> External Power Supply may vary by country.

# **Preset Display Modes**



- All information is subject to change without prior notice.
- HDMI™ VRR (Variable Refresh Rate) synchronizes with Adaptive-Sync (ON/ OFF). For VRR ON/OFF status, please check Adaptive-Sync.

	Resolution		Standard D	efault Mode	
Standard			HDMI™	DP	USB-C
VGA	640x480	@60Hz	٧	V	V
		@67Hz	٧	V	V
		@72Hz	٧	V	V
		@75Hz	٧	V	V
Dos-Mode	720x480	@60Hz	٧	V	V
	720x576	@50Hz	٧	V	V
SVGA	800x600	@56Hz	٧	V	V
		@60Hz	V	V	V
		@72Hz	٧	V	V
		@75Hz	٧	V	V
XGA	1024x768	@60Hz	٧	V	V
		@70Hz	٧	V	V
		@75Hz	٧	V	V
SXGA	1280x1024	@60Hz	٧	V	V
		@75Hz	٧	V	V
Full HD	1920x1080	@60Hz	٧	V	V
QHD	2560x1440	@60Hz	٧	V	V
		@120Hz	٧	V	V
		@144Hz	٧	V	V
		@165Hz		V	V
		@180Hz		V	V
Video Timing Resolution	720P		٧	V	V
	1080P	@60Hz	٧	V	V
		@120Hz	٧	V	V
	2160P	@60Hz	٧		
HDMI™ VRR			٧		

Chandrad	Bara Indian		Screen Size 16:10 (Not Support HDR)			
Standard Resolution			HDMI™	DP	USB-C	
QHD	2560x1600	@60Hz	٧	٧	٧	
		@120Hz	V	V	V	
		@144Hz		٧	V	
		@165Hz		٧	٧	

Standard	Desclution		PIP Mode (Not Support HDR)		
Standard	Resolution	Resolution		DP	USB-C
Full HD	1920x1080	@60Hz	٧	٧	V
QHD	2560x1440	@60Hz	٧	٧	V
Video Timing Resolution	720P		V	V	٧
	1080P	@60Hz	V	V	٧
	2160P	@30Hz	٧	V	
		@50Hz	٧	٧	
		@60Hz	٧	٧	

Standard.	Resolution		PBP Mode 1 (Not Support HDR)			
Standard			HDMI™	DP	USB-C	
Video Timing Resolution	720P		V	V	V	
Used for PBP	640x1440 @60Hz		٧	٧	٧	
Full Screen	1920x1440	@60Hz	V	V	V	

Chandand	Resolution		PBP Mode 2/Customize (Not Support HDR)		
Standard			HDMI™	DP	USB-C
Video Timing Resolution	720P		V	V	٧
Used for PBP Full Screen	1280x1440	@60Hz	V	V	V

### **Troubleshooting**

#### The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

#### No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

#### The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

#### No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

#### The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

#### The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

### Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

#### Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

#### **Environment**

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the device.
  - The device has been exposed to moisture.
  - The device does not work well or you can not get it working according to the User Guide.
  - The device has dropped and damaged.
  - The device has obvious sign of breakage.

### **TÜV Rheinland Certification**

### TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

#### TÜV Rheinland Flicker Free Certification

- TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.
- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

### Regulatory Notices

#### **CE Conformity**

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

#### FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

#### Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

#### MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

#### WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



#### Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

#### RoHS Statement

#### Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

#### India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

#### **Turkey EEE Regulation**

Conforms to the EEE Regulations of the Republic Of Turkey

#### Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017,  $\mathbb{N}^2$  139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

#### Vietnam RoHS


As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

#### **Green Product Features**

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- · Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

#### **Environmental Policy**

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.





#### Warning!

Overuse of screens is likely to affect eyesight.

#### Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

### **Copyright and Trademarks Notice**

# **MSI** 微星





Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

#### **Technical Support**

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.